



Easimount® Vinyl Strip Curtain System


Part Number: SA/LA#######

REQUIRED MATERIALS

- Easimount® Vinyl Strip Curtain System
- Drill with drill bits and Phillips head bit/screwdriver
- · Marking instrument
- Using the aluminum channel as a template, make sure channel is level and centered above opening. Bar height should allow strips to clear floor 1/4". Mark hole patterns with pencil (Fig. 1).
- Drill holes and mount channel with proper fasteners.
 Note: For flush mount freezer doors, shim aluminum channel off jamb 1/4" to increase space between vinyl strips and freezer door. (see below)
- 3. Insert one end cap at either end of channel.
- 4. Insert strips through un-capped end of channel (Fig. 2).
- 5. After verifying that all strips are evenly placed and overlapping properly, insert other end cap and trim strips if needed for proper floor height (**Fig. 3**).
- 6. Optional: Insert self-tapping screws at each end of channel through last strip for added retention.


CLEANING

Clean vinyl curtains with soap and water on a regular basis. For stubborn stains use a 5% ethanol (Windex type product) and water. Wipe curtain and any residual fluid on floor dry.



1. *Flush Mount Installation

FIG. 1



AIIACIIDA

FIG. 2



FIG. 3



GreenGuard®